



















EQ1

ASSEMBLY INSTRUCTION

Ax1 	Hx1 
Bx1 	Ix1 
Cx1 	Jx1 
Dx1(LxR) 	Kx5 
Ex1 	Lx5 
Fx1 	Mx3  M8x20mm
F1x1 	Nx2  M8x45mm
Gx5 	Ox16  M6x14mm
A1x1 	Px2  M6x30mm
	Qx2 